

# Frog Pod<sup>®</sup> Suction Cup Wall Bracket Instructions

The enclosed wall bracket uses suction cups to attach the Frog Pod to the bath wall. This option allows you to easily remove or re-position the Frog Pod.

## **WARNING**

- Adult assembly required.
- Prior to installation, remove all packaging materials and discard properly.
- The Frog Pod is not a toy!
- NEVER leave child unattended when bathing.
- This product should ALWAYS be used ONLY under adult supervision.
- Never apply excessive force to or allow children to hang from the Frog Pod.
- ALWAYS position the product on the lower portion of the bath wall.
- Suction cups are not toys. DO NOT allow children to play with them. Discard properly or store out of reach of children.
- ALWAYS clean mounting area prior to securing suction cups.
- DO NOT attach suction cups over ANY grout lines.
- When using the suction cup mounting option, DO NOT load the Frog Pod with more than 5 lbs. of toys and accessories.

NOTE: Select a position where ALL of the suction cups will be in direct contact with a SMOOTH, FLAT tile surface. Suction cups will NOT adhere properly when placed on grout lines or on tile surfaces that are not smooth.

### **Satisfaction Guarantee**

If for any reason you are dissatisfied with this product, please contact Boon Inc. so that we may address your questions or concerns.

info@booninc.com  
888.376.4763

[www.booninc.com](http://www.booninc.com)

**Step 1** Select a mounting location on the lower portion of the wall. Leave a minimum of 10 inches between the bottom of the bracket and any edge or raised surface of a bathtub below it.



**Step 2** THOROUGHLY clean wall surface with a household cleaner to remove any soap film or residue. Rinse THOROUGHLY and allow to dry completely. Be certain that you clean the entire area where the suction cups will be attached.

**Step 3** Next, VIGOROUSLY wipe area with rubbing alcohol. Let dry fully for AT LEAST 10 minutes.

NOTE: DO NOT wet suction cups before adhering to wall surface. BOTH wall surface and suction cups should be DRY when mounting the wall bracket.

**Step 4** Make sure hook is in the upward position and level. Place bracket onto the cleaned area and be certain that ALL suction cups are pressed down onto surface.



**Step 5** To attach base to bracket, fit slot over bracket hook and snap down into place.

