

Flair Disassembly Instructions



www.booninc.com

Please follow these instructions to disassemble your Flair highchair. If you have any questions or need additional assistance, please contact the Boon Customer Service Department at 888.376.4763 or info@booninc.com.

Tools needed: Phillips screwdriver, flathead screwdriver

Step 1 - Remove seat base cover and seat

Turn chair on side. Remove two bolts from seat base cover. Remove five bolts from seat bottom.



Step 2 - Remove support tube from base

Locate large gray disc in center of highchair base. The disc is attached with two plastic tabs. Use a screwdriver to pry one tab toward center of the disc while pulling the disk away from the base.



Locate the metal tab opposite the brake pedal in the center of the base. Use a screwdriver to pry up the tab while pulling the support tube out of the base.

